


ExciControl PC

Products / Software / 14/03/2016



ExciControl PC is used to make adjustments to the ExciControl 07-10 control system. You have options for adjusting speeds, ramps, frequencies and lots more. This software is easy to use and offers lots of options. You can save various settings on your PC, which you can then download to the control system with ease. This software is also ideal for simple troubleshooting, and users can translate easily into various languages.

Technical specifications

Technical data

Compatibility	Win 95 or higher
Data communication	RS 232

Analogue inputs

Quantity	8 functions
Individual adjustment	Progressivity, Zero band, Deadband, Max result


Analogue outputs

Quantity	8 functions
Individual adjustment	Frequency, Amplitude, Min current, Max current, Start ramp, End ramp

Digital inputs

Quantity	3 functions
Troubleshooting/ -measurement	Input voltage, Output current, Coil resistance

Languages and texts are edited with ease in a text processor.



EXCIDOR AB

Industrigatan 7
SE-821 41, Bollnäs
Phone +46 (0)278-136 70
info@excidor.se
www.excidor.se